



# PowerBook G4 Aluminum 15" 1-1.5 GHz Battery Replacement

Written By: iRobot



## INTRODUCTION

Changing the battery is easy -- all you need is a coin.



### TOOLS:

- [Coin](#) (1)



### PARTS:

- [G4 Aluminum 15" Replacement Battery \(New\)](#) (1)

## Step 1 — Battery



- Use a coin to turn the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-15 12:56:49 PM.