



iRobot Roomba 551 Dirt Bin Replacement

Remove the dirt bin on your Roomba.

Written By: Aaron Jacobs



INTRODUCTION

This guide explains how to remove the dirt bin from your Roomba either for cleaning or further disassembly.

Step 1 — iRobot Roomba 551 Dirt Bin Replacement



- Push on the dirt bin release button, and pull gently.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-03-22 11:59:29 AM.