



Canon EOS 300 Batteries Replacement

Guide for replacing used batteries with new ones.

Written By: Tammy Kong



INTRODUCTION

Where to put the batteries is easily accessible. The user will need two CR2 batteries for replacement.

Step 1 — Batteries



- Open up the battery door.

Step 2



- Remove the batteries from the camera by sliding them out into your palm.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 01:35:33 PM.