



Mr. Coffee DW13 Filter Replacement

Replace a broken or cracked filter.

Written By: Tess Bradley



INTRODUCTION

This is an easy replacement. All you need to do is open the top of the coffeemaker, move a black plastic arm, and lift the filter out of the machine.

Step 1 — Filter



- Face the top of the coffeemaker towards you.

Step 2



- Identify the two tabs on top of the machine.
- Lift the top of the coffeemaker up, using these tabs

Step 3



- Slide the black spout towards the back of the coffee maker, exposing the filter.

Step 4



- Using the side tabs, gently lift the filter up and out of the machine.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-19 08:00:47 PM.