



# Anker 2.4G Wireless Mouse Battery Replacement

How to replace the battery in an Anker 2.4G Wireless Mouse.

Written By: Vincent Lee



## INTRODUCTION

A new battery may be needed when the mouse is not working properly or not at all. For the Anker 2.4G Wireless Mouse it only needs 1 AA battery. While doing this make sure no metal tools are being used because if they touch the battery that could be a hazard. A good way to avoid something happening is using plastic opening tools and spudgers (nylon).

## Step 1 — Battery



- Remove the battery cover with a plastic opening tool, nylon spudger, or a fingernail.

## Step 2



- Remove the battery with a finger nail or a nonmetal tool.

To reassemble your device, follow these instructions in reverse order.