



Olympus Stylus 1030 SW Battery Replacement

Learn how to correctly remove and reinstall the Olympus Stylus 1030 SW battery


Written By: Simonas



INTRODUCTION


Outline what you are going to teach someone how to do.

Step 1 — Battery



- Release the battery door
- Release the battery

Step 2



- Align the battery so that the contact points are on the right (see photo)
- Insert battery

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-30 02:29:58 PM.