



# Olympus Stylus 1030 SW Battery Replacement

How to remove and reinstall the battery.

Written By: Simonas



## INTRODUCTION


Outline of how the steps are going to be performed.

## Step 1 — Battery



- Open the battery compartment cover.
- Release the battery.

## Step 2



- Push down on the SD card to release it.
- Insert battery.
- Insert SD through the slot on which it was taken out of.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-31 10:32:09 AM (MST).

