



Logitech M515 (Couch) Mouse

Over time, dirt and dust can get inside the M515 and clog up the buttons and scroll wheel. Here's how to open it up, I recommend using some compressed air to clean it.

Written By: Anna Sweetnam



INTRODUCTION

Taking the outer shell off is very easy and all of the internals are visible when it is removed.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)



PARTS:

- [Compressed Air](#) (1)
-

Step 1 — Removing the outer shell



- Remove the battery hatch and batteries.

Step 2



- Remove the single Phillips screw located between the battery sockets.

Step 3



- Lift the rear of the top case of the mouse and slide forward. It should be fairly easy to release.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-13 06:28:53 AM.