



# Audiovox CDM-8900 Battery Replacement

How to replace the battery in an Audiovox CDM-8900 flip phone.



Written By: Aaron Shaw



## INTRODUCTION

Here is how you remove the battery from the Audiovox CDM-8900.

## Step 1 — Battery



- Hold the phone in one hand, slide the latch up, and pull the battery up to remove it.

To reassemble your device, follow these instructions in reverse order.