



# Uniden TCX905 Battery Pack Replacement

This guide will show the user how to remove the battery pack.

Written By: Gary Pence



## **INTRODUCTION**



The battery is what charges the phone, and the phone will not operate without it. This must be removed in order to access the inside of the phone.

## Step 1 — Battery Cover



- Starting from the top of the cover, slide down and away from the phone with your thumb
- Lift battery cover off of batter and place it to the side

## Step 2 — Battery Pack



- Once battery cover is removed, place your thumb and index fingers on the the wires near the receptacle
- Gently pull straight up on the wires until a click is heard which signifies the battery is completely disconnected
- Place battery pack to the side

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 05:36:14 AM.