



Uniden TCX905 Battery Cover Replacement

This guide will show the user how to remove the battery cover.

Written By: Gary Pence



INTRODUCTION

The battery cover is what protects the battery pack of the phone. In order to access the battery and the other parts of the phone, the cover must be removed.

Step 1 — Battery Cover



- Starting from the top of the cover, slide down and away from the phone with your thumb
- Lift battery cover off of batter and place it to the side

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 09:17:28 PM.