



# Dell Inspiron 1750 Battery Replacement

This is a guide for the replacement of the Dell Inspiron 1750 battery.

Written By: Jordan Nedbailo



---

## INTRODUCTION

This guide will help you replace the battery of your Dell Inspiron 1750. You may need to perform this replacement if your battery leaks or does not charge anymore.

---

-  **PARTS:**
- [Dell Inspiron 1440, 1750 Replacement Battery \(312-0940\)](#) (1)
-


## Step 1 — Battery



 Unplug the laptop before changing the battery to avoid electric shock.

- Place the laptop on a flat stable surface.
- Flip the laptop over so the underside is visible.

## Step 2



- Locate the battery lock switch.
- Slide the lock switch to the left (away from the lock symbol).
- Slide the battery out away from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-10 06:33:09 PM.