



# Sony Tablet S Factory / Hard reset

Sony Tablet S Factory / Hard reset

Written By: ZFix

# SONY



# XPERIA Tablet S

## INTRODUCTION

If you have a problem with starting-up the OS, or if you want to erase all data, or you forgot your password, PIN, pattern code you can do a Factory reset.

Attention!!! This will erase all your data!!! It's good to do **BACKUP** first.

[Please SUBSCRIBE to my channel ツ](#)

[video: <https://www.youtube.com/watch?v=9NM2znQk558>]

## Step 1 — Sony Tablet S Factory / Hard reset



### ● **Metod 1:**

- - Settings
- - Backup & reset
- - Factory data reset
- The tablet will restart automatically.
- **!!! From the "Backup & reset" menu you can do Back up my data !!!**

## Step 2



### ● Metod 2:

- Power of the tablet. Pres and hold the Power On key and the Volume Up key at the same time.
- When you see the Sony logo release the Power On button but continue to press the Volume Up button.
- Now you are in the **Android recovery menu**. Use Volume keys to scroll and the Power On key to select. From the options select:
  - - Reset to Factory Settings
  - - Yes - erase all user data
  - - The tablet will restart alone
  - [Please SUBSCRIBE to my channel 🙄](#)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 11:29:40 AM.