



Nintendo 3DS XL Battery Replacement

You will be able to remove the battery of the Nintendo 3DS XL which will enable you to replace it.

Written By: Charlene Donlon



INTRODUCTION

Battery having issues and need to be placed? This guide will take you through the steps necessary to have a new battery in your Nintendo 3DS XL in no time!

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #000 Screwdriver](#) (1)

PARTS:

- [Nintendo 3DS XL \(2012 or 2015\) Battery](#) (1)
- [Nintendo 3DS XL Battery Cover](#) (1)

Step 1 — Battery



- Loosen the two 4.2 mm-length screws located at the top of the back cover.
- ⓘ The screws have locking washers that prevent the screws from falling off of the back cover. Leave these locking washers on the screws; it is not necessary to remove the washers for this repair guide.

Step 2



- Hold the device so that the cover is facing up.
- Using a plastic opening tool, pry off the cover starting at the top right corner.
 - Hold the edge of the cover to ensure it does not reattach.
 - Look for the small section below the stylus compartment. Pry off the cover at that point if it is still attached.
- Take off the cover of the device and set aside.

Step 3



- Insert the plastic opening tool into the opening located on the right side of the battery.
- Pry off the battery from the lower casing.
- Lift the battery out of the case and set aside.

To reassemble your device, follow these instructions in reverse order.