



Gateway NV52 Battery Replacement

This guide will easily teach you how to remove the battery from your laptop.

Written By: Tim En



INTRODUCTION

The battery pack will be the first prerequisite for the other components inside the laptop.

Step 1 — Battery



- Turn the laptop on its backside with the stickers and barcode facing you.
- Locate the latches on the top left corner.

Step 2



- In order to unlock the battery, slide the vertical latch downward where it indicates the unlocking icon.

Step 3



- Slide the horizontal latch to the right to pop open the battery pack.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-08 09:50:35 PM.