


# Nokia 6086 Screen Replacement

Written By: Caitlin Rahm



## **INTRODUCTION**

Replacing a damaged screen.



# **TOOLS:**


- T6 Torx Screwdriver (1)
- iFixit Opening Tools (1)

#### Step 1 — Battery



- Turn off the phone.
- Check if there is a microSD card in the slot behind the door on the side.
  If so, remove it by first pushing it in, then pulling it out.
- Position the phone so that the back side is in view.


## Step 2







- Remove the back battery cover.
  - Apply pressure on the cover while simultaneously sliding the cover downward.








- Insert the iPod opening tool between the base of the phone and the phone battery.
- Position the phone so that the battery won't fall out of the phone.
  - (i) The battery lifts out of the phone fast and easily.
- Carefully lift the battery out of the phone.

#### **Step 4** — **Top Front Cover**



- Close the phone.
- Face the front cover forward.






- Locate the 4.5 mm notch at the top of the phone.
- Place the iPod opening tool into the opening.
- Slightly prop up the top section by lifting the tool.








- Wedge the iPod opening tool between the top cover and the phone.
- Gently lift the top cover away from the phone using the iPod opening tool.
  - This unlatches each hook that connects the top cover to the phone.
- (i) Repeat for both the left and the right sides of the phone.
- Place the top cover aside once the top cover is completely disconnected from the phone.


#### Step 7 — Screen








- Locate the four screws on the phone.
  - The top right screw is located under the black connector piece.
  - (i) To remove the connector piece gently lift it off of its connector.
- Take the T6 driver and remove the screws.




Carefully lift up the motherboard.

# Step 9





- Find the orange slip on the motherboard.
- Peel back the orange slip to expose the screen.







- Place the ipod opening tool under the screen.
- Remove the damaged screen with the ipod opening tool.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 02:28:12 AM.