




# Canon EOS Rebel T1i Rubber Grip Replacement

If the rubber grip on the camera is dirty or has fallen off, follow these instructions to remove the grip.

Written By: Jonathan Lin



---

## INTRODUCTION

If the rubber grip on the camera is dirty or has fallen off, follow these instructions to remove the grip.



### TOOLS:

- [Pry Bar](#) (1)



### PARTS:

- [Canon T1i Rubber Grip](#) (1)
-

## Step 1 — Rubber Grip



- Use a plastic prying tool to slowly pry the rubber grip from the top right corner, and slowly work the tool down the rubber grip.
- Gently remove the rubber grip by pulling the adhesive side up and away from the camera.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-03-27 10:14:05 PM.