



Disassembling HTC Incredible 2 Back Panel

How to remove the back panel to access device's interior components.


Written By: Jonathan Morsch



INTRODUCTION

Is there something you want to fix inside your phone? This guide will show you how to remove the back case to access internal components.

Step 1 — Disassembling HTC Incredible 2 Back Panel



- Press your thumbnail into the slot between the rear panel and the front casing located on the bottom of the phone. Use a penny or dime if you have trouble using your thumbnail.
 - With a moderate amount of force, pry the rear panel up and away from the phone. You may need to slide your thumbnail up the crack to separate the rear panel from the front casing.
- i** This can take a little bit of effort. Don't be discouraged if you can't get it right away.

Step 2



- Remove the rear panel from the phone.

To reassemble your device, follow these instructions in reverse order.