



# Panasonic Camera DMC-FX07 Battery Replacement

You won't need any tools, this will show you how to take the battery out

Written By: Duncan Rutherford



## **INTRODUCTION**

I am going to show you how to take the battery out.

## Step 1 — Battery



- The first step is to turn off the camera
- Next, locate the battery door on the bottom of the camera
- To open, slide the latch left, or towards the tripod mount
  - The door should spring open

## Step 2



- Now that the door is open, release the spring clip on the right
  - The battery should pop out just enough so you can pull it out
- Pull the battery out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-11 12:36:04 AM.