



Toshiba Satellite M45 Battery Replacement

Written By: Stephen



INTRODUCTION

This guide describes how to replace the battery of the Toshiba Satellite M45 laptop.

Step 1 — Battery



- If the device is still running, please turn the computer off properly and then disconnect the power supply from the power supply port in the back of the computer.
- Remove battery before beginning any work to reduce electrical shock and to prevent damage to the electrical components.
- Locate and slide the 2-battery locks to disconnect the battery.
- Remove the battery by sliding it out away from the computer (horizontal with the casing).