



iPhone 5c Pentalobe Screws Replacement

5-point Pentalobe screws replacement.

Written By: Sam Goldheart



INTRODUCTION

This guide shows how to remove the Pentalobe screws on your iPhone 5c.

TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)
-

Step 1 — Pentalobe Screws



- Use the Pentalobe screwdriver to remove the two 3.8 mm Pentalobe screws near the dock connector.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-19 03:47:49 AM.