



LG L1200 SIM Card Replacement

Written By: Joshua Herrmann



INTRODUCTION

This guide will help you replace this phone's SIM card.

Step 1 — SIM Card



- Remove the battery from the back of the phone by lifting up the tab.

Step 2



- Push the SIM Card up using your thumb until it is removed.

Step 3



- Once removed, replace with new SIM Card, making sure that the cut corner fits into the cut corner of the slot.

This document was last generated on 2019-07-09 05:02:26 PM.