



# Samsung Galaxy S5 microSD Card Replacement

Replace or remove the microSD Card in your Samsung Galaxy S5.

Written By: Walter Galan



---

## INTRODUCTION


Use this guide to replace the microSD card.

---

### TOOLS:

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Rear Case



- Insert a fingernail or plastic opening tool into the divot to the left of the rear-facing camera.
- Gently pry and twist the flexible rear cover off the back of the phone.

## Step 2 — Battery



- Insert a fingernail or plastic opening tool into the recess in the bottom right corner of the battery and lift upward.
- Remove the battery away from the phone.

### Step 3 — microSD Card



- Using a fingertip, pull the microSD card straight down out of its slot.
- Remove the microSD card from the phone.

To reassemble your device, follow these instructions in reverse order.