MacBook Core Duo Battery Replacement

MacBook Core Duo battery replacement.

Written By: iRobot

INTRODUCTION

If you've got a coin, you can replace the battery in your MacBook Core Duo.

🔧 **TOOLS:**

- Coin (1)

⚙ **PARTS:**

- MacBook Replacement Battery (1)

Step 1 — Battery

- Use a coin or spudger to rotate the battery-locking screw 90 degrees clockwise.

Step 2

- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-13 04:36:20 PM (MST).