



Disassembling Nokia 3395 Front Case

Remove the front cover

Written By: Nico Lee



INTRODUCTION


Removing the case is easy - all you need are your hands!

Step 1 — Back Case



- Hold the phone and push the white button with your thumb.
- While pressing the button, slide the back plate up (towards the top of the phone) and off the phone.

Step 2 — Front Case



- Where shown, spread the front faceplate and push forward.
- Flip over the device, and pry the faceplate away.

To reassemble your device, follow these instructions in reverse order.

