

INTRODUCTION

This guide will explain how to remove the battery.

Step 1 — Battery



- Begin by turning the laptop over so that you can see the bottom of the computer.

Step 2



- Slide the battery release switch to the right while simultaneously lifting up the battery.

To reassemble your device, follow these instructions in reverse order.