



Panasonic PV-GS9 Battery Replacement

Written By: Trevor Johnson



INTRODUCTION

The first step in the repair process for the Panasonic PV-GS9 is to remove the Battery from the Camcorder.

Step 1 — Battery



- ⓘ While holding the Camcorder firmly, pull down on the battery removal tab located on the underside of the camcorder.

Step 2



- Then, pull the battery down away from the camcorder. Pull out as it becomes free.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 01:23:09 PM.