



Nexus 7 Black Screen Fix

If you don't charge Nexus 7 for too long, it can self-discharge to a point where it won't power up. This is one way to fix this problem.


Written By: Alan Nishioka



INTRODUCTION

If you don't charge Nexus 7 for too long, it can self-discharge to a point where it won't power up.

Step 1 — Nexus 7 Black Screen Fix



- **Symptoms:**
 - 1. Nexus 7 won't power on.
 - 2. Battery icon doesn't show when charger plugged in.
 - 3. In a dark room, you can see backlight is turned on. If you hold down power button for 30 seconds, you can see the backlight power cycle.
- **Solution:**
 - 1. Hold down both volume buttons (Press the center) and plug in charger (while holding the buttons). Hold down for 40 seconds.
 - 2. Hold down power button 40 seconds to boot Nexus.
 - In the future, don't let battery discharge too much.

This procedure has been used to fix 25 Nexus 7 tablets which were unopened for months and allowed to discharge too far.

This document was last generated on 2019-07-14 04:27:15 PM.