



How To Remove the Battery Back Plate

This is a step-by-step guide on how to remove the battery back plate on JVC GR-D290U camera.

Written By: justin chen



INTRODUCTION

The following guide is a step by step guide on how to remove the battery back plate on a JVC GR-D290U camera to gain access to the battery if it needs to be replaced.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — How To Remove the Battery Back Plate



- Remove the two screws on the underside of the camera eyepiece.

Step 2



- Remove the two screws connecting the back plate to the camera base.

Step 3



- Remove the back plate.

To reassemble your device, follow these instructions in reverse order.