



# Disassembling IBM ThinkPad T42 Rear Cover

Written By: Gerald Watanabe



---

## INTRODUCTION

The disassembly of the rear cover is simple but requires the removal of a lot of screws.

---

### TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Bottom Cover



- Unscrew the 20 Phillips screws on the underside of the T42.
- ⓘ For ease of reassembly, keep your screws organized.

## Step 2 — Rear Screws



- Unscrew the 2 Phillips screws on both sides of the T42's rear.

To reassemble your device, follow these instructions in reverse order.