



Air Blasters Tek Six Barrel Replacement

Replace the barrel of your Air Blasters Tek Six in case it does not work properly.

Written By: Joshua Taylor



INTRODUCTION

The barrel is the orange piece into which you insert the darts.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Remove screws of the grey slider




- Using a screwdriver, remove the two 11.6 mm phillips 00 screws holding the grey slider together.
- Remove grey slider from the main body of the blaster.

Step 2 — Remove screws in main body



- Using a screwdriver, remove the six 9 mm phillips 00 screws holding the main body together.

Step 3 — Take the main body apart



- Using the plastic opening tools, carefully take apart the main case of the blaster to leave the inside exposed.

Step 4 — Remove the trigger



- Remove the trigger, lifting from the bottom and pulling it out from under the metal pin.

Step 5 — Removing the barrel



- Lift the barrel, pulling it out from under the black trigger catch

To reassemble your device, follow these instructions in reverse order.