



Kid Galaxy Morphibians Explorer Battery Replacement

Removal of the battery cover will give you access to the battery case within the Kid Galaxy Morphibians Explorer.

Written By: Rusbell Gonzalez



INTRODUCTION

There are only a few steps that you need to take in order to replace the batteries.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Battery



- First, completely loosen the 9.6 mm Phillips #2 screw on top. There is a plastic washer that holds the screw to the top cover, so it will not need to be taken out.

Step 2




- After the screw has been loosened, lift the cover off.

Step 3



- Completely loosen the 9.6 mm Phillips #2 screw from the battery cover. Once again, there is a plastic washer to hold the screw to the cover.

Step 4



- Lift the battery cover to gain access to the batteries.
- Replace the 3 AA batteries and reverse the steps to put everything back together.

To reassemble your device, follow these instructions in reverse order.