



Eureka AirSpeed Bagless Zuum Vacuum Hose Replacement

If there is no suction, this guide outlines the replacement of the major suction connection within the mechanism of the vacuum.

Written By: Celina Burchett



INTRODUCTION

If you determine there is no suction at the end of the hose, this guide will help you to replace a damaged hose.

Step 1 — Hose



- On the back of the vacuum, pull the handle connected to the hose away from the vacuum.

Step 2



- Grasp the thick smooth collar at the bottom of the hose and twist left (counterclockwise) to remove the hose.

To reassemble your device, follow these instructions in reverse order.

