



# Nintendo DSi XL Rear Bezel Replacement

Rear bezel replacement.

Written By: Matthew Newsom



## INTRODUCTION

Be the envy of onlooking gamers with a shiny new rear bezel on your DSi XL.



### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Push Pin](#) (1)
- [Spudger](#) (1)



### PARTS:

- [Nintendo DSi XL Outer Shell](#) (1)

## Step 1 — Rear Bezel



- Use a push pin to remove the four plastic screw covers on the front bezel.

## Step 2



- Remove four Phillips screws securing the front bezel to the rear bezel.

### Step 3



- Using two hands, gently slide the rear bezel upwards.
- ⓘ The rear bezel will move only about 2 mm.

### Step 4



- Insert a spudger into the gap between the front and rear bezel
- Rotate the spudger away from the DSi XL, prying the two bezels apart.

## Step 5



- In the same manner as described above, continue prying along the top edge of the front and rear bezels.

## Step 6



- Separate the rear bezel from the front bezel.
- ⚠ Do not attempt to completely remove the rear bezel yet. It is still attached to the front bezel by the rear-facing camera.

## Step 7



- Use the flat end of a spudger to pry the rear camera off the rear bezel.
- Remove the rear bezel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-13 11:29:26 AM.