



Xbox 360 Wireless Controller Battery Replacement

Battery replacement.

Written By: Brett Hartt



INTRODUCTION

Controller dying regularly? Put in a freshly-charged battery and own the living room once again.



PARTS:

- [Xbox 360 Rechargeable Battery](#)[Xbox 360 Rechargeable Battery 2-Pack](#) (1)
 - [Xbox 360 Wireless Controller Battery Enclosure](#) (1)
-

Step 1 — Battery



- Depress the battery release button on the top of the controller.
 - Remove the battery holder from the controller.
- i** The standard option for Xbox 360 Wireless Controllers Battery Packs is AA batteries. A rechargeable battery is also available, but both battery options are removed from the controller in the same way.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 03:39:14 PM.