




Lenovo ThinkPad Edge E530 DDR3 SODIMM SDRAM Replacement

Lenovo ThinkPad Edge E530 DDR3 SODIMM SDRAM Replacement

Written By: ZFix



INTRODUCTION

How to change / upgrade SDRAM Memory

How to fully disassemble Lenovo ThinkPad E530 - Video manual:

[video: <http://youtu.be/MM-G4OkeagQ>]



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:


- [DDR3 1333 SO-DIMM RAM](#) (1)

Step 1 — HDD Cover



- Switch-off the Laptop and remove the battery.
- The HDD/Memory Cover is held by 3x Phillips screws. Remove them.
- Remove the Cover.

Step 2 — DDR3 SODIMM SDRAM



- This model has 2x slots for SODIMM SDRAM.
- For **ThinkPad Edge E530** you can install 2x modules DDR3 SODIMM up to 16GB.
- For **ThinkPad Edge E530c** you can install 2x modules DDR3 SODIMM up to 8GB.
- **Did you do it successfully?**

To reassemble your device, follow these instructions in reverse order.

