



Kindle Fire HD 6 Back Panel Replacement

This guide will show you how to remove the back panel from your Kindle Fire HD 6.

Written By: 000



INTRODUCTION

Removing the back panel of the Kindle Fire HD 6 is very important, because you can't access any of the other components until you remove the back panel. In this guide, we'll cover how to remove this panel so that you can replace the components inside.

TOOLS:


- [iFixit Opening Tools](#) (1)

Step 1 — Back Panel



- Place the device face down on a clean cloth or another smooth surface.
- ⚠ In the following steps, you will need to apply some force to your device. If your device is on a rough surface, you may scratch the screen.
- Insert the plastic opening tool between the device's front and back panels. You might need to wiggle the tool up and down to wedge it in the gap.
- Maneuver the tool around the device until the back unclips from the front panel.

Step 2



- Carefully separate the back panel from the rest of the device internals.

To reassemble your device, follow these instructions in reverse order.