



HP TouchSmart 15-r015dx Battery Replacement

This guide will show you how to remove and replace the battery of your HP TouchSmart 15-r015dx.

Written By: Jacob Kleinsorge



This document was generated on 2020-11-19 07:48:16 PM (MST).

INTRODUCTION

The HP TouchSmart 15-r015dx has a 3-cell lithium-ion polymer battery that fits nicely on the bottom of the laptop.

Step 1 — Battery



- ⓘ Turn off your laptop.
- ⚠ Ensure your laptop is off. Removing the battery while it is on may harm your laptop or yourself.
- Flip over to view the bottom of the laptop in order to gain access the battery and the DVD±RW Drive.

Step 2



- There are two battery release switches circled, slide both switches inward to release and remove the battery.

To reassemble your device, follow these instructions in reverse order.