
JVC Adixxion GC-XA1BU Battery Cover Replacement

To complete this guide, you will need to...

Written By: Christina Michelle Johnson



INTRODUCTION

To complete this guide, you will need to purchase a new battery compartment cover and make sure that you have the tools listed. While it is not necessary to remove the battery to be able to remove the battery cover, it is always good practice to make sure that the device is completely powered off before attempting any repairs.

TOOLS:

Phillips #00 Screwdriver (1)

PARTS:

JVC BN-VH105US Battery Pack (1)

Step 1 — Battery



- Find the side of the camera with the black switch shown.

Step 2




- Push down on the black switch.

Step 3



- Slide the battery cover back while pushing down on the black switch.

Step 4






- Open the battery compartment and push the blue battery release switch.

Step 5



- Remove the battery from the camera.

Step 6 — Battery Cover



- Remove the two Phillips screws (4mm x 3mm) using the Phillips #00 screwdriver.

To reassemble your device, follow these instructions in reverse order.