



# Asus X200MA Keyboard Assembly Replacement

In order to get to the inside of the laptop, these steps will help guide you through removing the keyboard assembly.

Written By: Vanessa Garcia



 **TOOLS:**

- Phillips #0 Screwdriver (1)
  - Spudger (1)
-

## Step 1 — Back Panel



- Remove the following six screws:
    - Six 4 mm Phillips #0 using a phillips screddriver
  - Remove the following one screw:
    - One 14 mm Phillips #0 using a phillips screwdriver
- The 14mm screw goes in the center.

## Step 2



- Use a plastic or metal spudger to separate the keyboard from the back panel and lift the keyboard out of place.

To reassemble your device, follow these instructions in reverse order.