




Kindle Touch Back Cover Replacement

"Prerequisite Only"

Written By: Adam Yerly



Step 1 — Back Cover



- With the small plastic opening tool, undo the plastic clips around the back lid.

Step 2



- Gently lift the bottom and pull as the rest of the plastic guides are on a track.

To reassemble your device, follow these instructions in reverse order.