



# HP Pavilion dv5000 Battery Replacement

How to replace your battery.

Written By: Farid Khoshnevisan



## **INTRODUCTION**

How to replace your battery.

## Step 1 — Battery



**⚠** Turn off and unplug the computer from all external power sources.

- Shut the screen, and lay the computer face-down on a flat, sturdy surface. Orient the computer to match the image.
- Locate the battery release switch, as indicated in the image. Sliding this switch from right to left will release the battery.
- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-05-21 12:18:29 PM.