



# Acer Aspire 5100 Keyboard Replacement

Install a new keyboard for an Acer 5100 laptop.

Written By: Brad Rollinson



## INTRODUCTION

Install a new keyboard for an Acer 5100 laptop.



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)




### PARTS:



- [Replacement Keyboard](#) (1)

## Step 1 — Keyboard



- Open and push the screen back all the way until it is horizontal with the rest of the laptop.
- Locate the panel above the keyboard that has the power button on it.
- Remove this panel by using a spudger to pry up the sides.
-  You are using the spudger to release tabs holding the panel in place.
- After you have used the spudger to release the tabs, lift up the panel.

## Step 2



- Under the panel, locate and remove the two screws that connect the keyboard to the laptop. One screw is located above the F5 button, and the other one is located above the F10 button.

⚠ Lift up the keyboard CAREFULLY because there is a ribbon that connects the keyboard to the motherboard.

### Step 3



- Release the catch on the ribbon socket, by sliding the two tabs toward the ribbon, then pull the ribbon, which is located under the keyboard, to detach it from the motherboard.
- Remove the keyboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-17 05:31:27 PM.