




# iRobot Roomba 4100 Battery Pack Replacement

The Roomba 4100 battery will need to be replaced every 1-2 years depending on use.


Written By: Scott Leonard



## INTRODUCTION

This guide covers the Roomba 4100 battery replacement.

## Step 1 — Battery Pack




- The Roomba Battery is the central yellow block under the Roomba's front bumper. Refer to the top of the graphic.

## Step 2



- Remove the battery by pressing the tabs on both sides of the device, as demonstrated.
- Gently lift the battery up and out of the device.

## Step 3



- Purchase or obtain a replacement battery from the manufacturer. Then simply drop the new battery into place.