




iRobot Roomba 4100 Battery Pack Replacement

The Roomba 4100 battery will need to be replaced every 1-2 years depending on use.


Written By: Scott Leonard



INTRODUCTION

This guide covers the Roomba 4100 battery replacement.

Step 1 — Battery Pack




- The Roomba Battery is the large yellow block under the Roomba's front bumper.

Step 2



- Remove the battery by pressing the two side tabs, as demonstrated.
- Gently lift the battery up and out of the device.

Step 3



- Obtain a replacement battery cell from the manufacturer. Simply drop the new battery into place.

This document was last generated on 2019-07-16 10:07:38 PM.