



# Archos 97 Carbon Display Screen Replacement

Use this guide to remove display screen in your Archos 97 Carbon tablet.

Written By: Allyson Seber



---

## INTRODUCTION


If you want to replace the screen on your tablet, then this guide is for you. Use this step by step guide on how to properly replace the display screen on your Archos 97 Carbon tablet.

---

### TOOLS:


- [Tweezers](#) (1)
  - [Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Display Screen




- Lay your tablet upwards facing you.
- Using the opening tool, being prying the tablet starting in the top left corner near the volume and power button. Then work your way around in a clockwise motion to separate the screen from the back cover.

## Step 2



- Once you have opened the screen, you will see two cables that connect the screen and the interior of the tablet.
- Remove the white tab located on the right side of the interior by removing the tape and plug that connects it to the tab.


### Step 3



- i On the left side of the tablet, you will see a silver cable connecting the screen to the motherboard.
  - Using the tweezers, remove the black tape that is connecting the cable and screen. This will allow the gold connector to come loose.
- i The screen should be separated from the tablet.




## Step 4



- Remove the screws on the backside of the screen using a screwdriver.

**i** There are four screws; one is covered by tape.

## Step 5



- Gently pry the screen from the black frame that surrounds it using the opening tool.

**i** Work in a clockwise motion until the screen is detached from the frame.

To reassemble your device, follow these instructions in reverse order.