



Sony Ericsson z300 Front Dark Grey Case Replacement

Remove the case in order to access the Screens.

Written By: Alex Serventi



INTRODUCTION

This guide will show you how to remove the Dark Grey case that allows you access to the Screens.

TOOLS:

- [T5 Torx Screwdriver](#) (1)
-

Step 1 — Front Phone Cover



- To remove the front cover, lift up the case with a fingernail in the small slot as shown.

Step 2 — Front Dark Grey Case



- To remove the front grey case, remove the two screws shown with a T5 Torx Screwdriver.

Step 3



- Pry up the dark grey case with your fingernail until all four snaps around the top are loose.

Step 4



- Lift up towards the bottom and slide the case off.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-25 04:17:20 AM.