



# Olympus FE-170 Batteries Replacement

This guide will show you how to remove old, dead batteries in your camera, and replace them with new, changed batteries.

Written By: Tyler Hartwig



## Step 1 — Batteries



- Press the button on the hatch next to the "PUSH" label on the bottom of the camera.
- Gently slide the battery hatch out until it releases.

## Step 2



- Pull the batteries out of the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-14 09:11:47 PM.