




# Compaq Mini 110 RAM Replacement

Remove or replace RAM in the Compaq Mini 110.

Written By: alea



## INTRODUCTION

Use this guide to access and replace your RAM. Disconnect all power sources and remove the battery pack before beginning this repair.



### TOOLS:



- [Phillips #0 Screwdriver](#) (1)



### PARTS:


- [PC2-5300 1 GB RAM Chip](#) (1)
- [PC2-5300 2 GB RAM Chip](#) (1)

## Step 1 — RAM



- Find and remove the two screws on the bottom of your Compaq Mini covering the memory compartment.
- ⓘ Note that the screws are attached to the panel.

## Step 2



- Push out side tabs.

To reassemble your device(possibly install a new RAM), follow these instructions in reverse order.

This document was last generated on 2019-08-15 10:35:58 AM.