



Bose SoundDock Portable v2 Remote Battery Replacement

Replace the remote battery.

Written By: Brodie Sutherland




INTRODUCTION

This guide shows you how to replace the battery in your remote

TOOLS:

- [Coin](#) (1)
-

Step 1 — Remote Battery



- Using a quarter, turn the battery cover 1/8th of a turn counterclockwise.

Step 2



- Remove cover and battery. The new battery should be placed with the positive (flat) side facing up.
- **i** The correct battery for your remote is a CR2032. You may also use a DL2032.

To reassemble your device, follow these instructions in reverse order.